



STEP DOWN BALLET BAR


ITEM# PSBBDTADJ







1 BY HAND, SCREW IN THE CROSSBAR TO FOOT AS SHOWN. TIGHTEN FULLY.

2 BY HAND, SCREW THE FOOT TO CROSSBAR AS SHOWN. TIGHTEN SUFFICIENTLY & MAKE SURE IT ALIGNS WITH THE OTHER FOOT AS SHOWN BELOW






3 SCREW IN THE CASTERS AS SHOWN USING PROVIDED WRENCH





4


BY HAND, SCREW IN BOTTOM UPRIGHTS AS SHOWN



- 5 BY HAND, SCREW ADJUSTABLE CONNECTOR TO BOTTOM UPRIGHTS SUFFICIENTLY & THEN ADJUST SO THAT IT ALIGNS AS SHOWN BELOW
- 6 TIGHTEN SET SCREW USING HEX WRENCH TO LOCK ADJUSTABLE CONNECTOR IN PLACE.




7



7

BY HAND, SCREW TOP UPRIGHTS TO HANGBAR AS SHOWN



8 (UNTIGHTEN HAND WHEEL)
DROP HANGBAR FROM STEP 7 AS SHOWN AT DESIRED HEIGHT
& LOCK IN POSITION BY TIGHTENING THE HAND WHEEL